





KEXIN INDUSTRIAL CO., LIMITED

Heavy Duty Steel Brackets With Lift-Up Hydraulic Pistons For Under Bed Storage

Contains One (1) mechanism set and hardware.



COMPONENTS & HARDWARE





*Wood screws not included



INSTALLING THE LIFT MECHANISM TO THE BED BASE

1. Start by attaching both lift brackets to the inside of the bed base towards the head of the bed (wood screws not included). The bottom arm of the brackets must be parallel to the top and bottom edges of the bed base.
2. Next, attach the thinner ends of the pistons to the bottom pin on the lift brackets.




3. Place the frame onto the lift mechanisms.




4. Use the screw and nut provided to attach the frame to the lift mechanisms.

Attach the nuts, but wait until the last step to tighten them.



5. Lift the frame up and secure in place by attaching the top of the pistons to the remaining pin on both brackets. This will give you access to tighten the nuts under the frame.



6. Use the slots on the lift mechanism to adjust the position of the frame.

Did you know?

This hydraulic lift storage system can also be installed onto a plywood base.



Please note: The mechanism operates properly once the mattress is on the frame.

SAFETY GUIDE



Not for children to play on or under.



Please keep limbs away from the bed opening when operating the mechanism.

HOW TO USE



Lift the bed from the **center** of the frame from the foot of the bed only.



To lower the bed, pull down from the **center** of the frame or push down on the **center** of the mattress from the foot of the bed only.